

Hardware reset

In the event you need to perform a full hardware reset, on a master or expansion controller, follow the simple steps below:

1. Remove power from the controller
2. Remove the wiring from the Reader 1 connector
3. Connect the Reader 1 Red LED terminal to Reader 1 Media Detect terminal using a piece of jumper wire
4. Connect power to the controller
5. The OK LED will flash on and off quickly a few times
6. The OK LED will return to a normal slow flash (equal on and off time) indicating that it is back in normal mode and trying to connect
7. Remove power from the controller
8. Remove temporary reset connection (step 3)
9. Replace Reader 1 wiring (if appropriate)
10. Connect power to the controller

Your controller is now default and you will need to reinstate your controller via the web page