

Connecting a Honeywell Omniclass Reader to Net2

Overview



In Net2, Door Settings, change "Reader Type" to "Wiegand Reader".
A Customer Wiegand filter will need to be set up in the Server Configuration utility if you require to read specific user data from the card.


It is not possible to use the tamper function with Net2.

Reader can be supplied in: Wiegand 26-bit and 34 bit smart cards.
Operating Frequency: 13.56 MHz.
Compatible Cards: Prox 125kHz; Mifare® Compatible ISO-14443A

Further information on use and programming is available at:

<https://buildings.honeywell.com/gb/en/products/by-category/access-control/>

	Cable Pinout	ACU terminal
	Red	+12V
	Brown	Red LED
	-	Amber LED
	Orange	Green LED
	Green	Wiegand D0
	White	Wiegand D1
	-	NOT USED
	Black	0V



Ensure any unused wires are safely terminated.

To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.

 +44 (0)1273 811011
support@paxton.co.uk
paxton.support


 +49 (0) 251 2080 6900
support@paxton-gmbh.de
paxton.gmbh.support


 +33 (0)157 329356
support@paxtonaccess.fr
paxton.support

 +32 (0)78485147
support@paxton-benelux.com
paxton.benelux.support


 +31 (0)76 3333 999
support@paxton-benelux.com
paxton.benelux.support

 +27 (0)21 4276691
support@paxtonaccess.co.za
paxton.support

 +1(800) 672-7298
supportUS@paxton-access.com
usapaxton.support

 +11 5715088198
soporte@paxton-access.com
paxton.soporte

 +1 (864) 751-3501
soporte@paxton-access.com
paxton.soporte

 8000 3570 3783
support@paxtonaccess.ae
paxton.support

 +44 (0)1273 811011
support@paxton.co.uk
paxton.support