

Net2 - Nano

System specifications

Maximum total users/tokens 10,000 4 PIN Lenath Number of codes 50 Code lenath 4 - 8 Number of time zones 64 Number of access levels 250 Stored events 3800 Data retention during a total 60 days

power loss

Handsfree compatible

Yes - requires interface

Yes

Clock and data

26 bit Wiegand Custom Wiegand

Silent operation Nο

Door open time

1 sec - 999,999 secs

Yes (Max 50 bits)

Yes (Max 50 bits)

Electrical

10V - 14V DC Operating Voltage Current consumption 120mA Relay switchable voltage 24V DC

Relay switchable current 4A Alarm output current 1A

Communication

TCP/IP No Wireless Yes RS485 No Recommended wireless devices 10

per Net2Air Bridge

Optimum wireless range

Encryption AES 128bit

Hardware

Reader ports per ACU

Readers/Keypads per ACU 2 - check current draw on individual readers

Total ACU reader port output

20m/65ft

3rd party reader support

Yes - if compatible

Reader cable type

Belden 9540/9538

Input for exit button Yes Input for door contact Yes Alarm/bell output Yes 12V DC lock output 1.1 Amp


Operating temperature

0°C - +55°C

Moisture resistance

No - if used externally, it must be protected in a weatherproof housing

Vandal Resistance low



Net2 nano communicates with Net2 software at a central point by a secure, low power radio link. This means that your installation is more cost effective and less disruptive as no cable is required to communicate between doors. In addition, Net2 nano benefits from unique ease of installation and configuration - no knowledge of networks is required.


One Net2 nano controls a single door, gate or barrier. It may be installed as part of a Net2 installation alongside other Net2 nano, Net2 plus or Net2 classic access control units.

Simply connect a Net2Air USB bridge to the central Net2 server PC and the Net2 software will discover and communicate with Net2 nano control units within range. A secure pairing procedure ensures that communications are private and restricted to the site. If there is an existing TCP/IP Ethernet network, a Net2Air Ethernet bridge may be used to extend the communication distance from the central server PC.

As with all Net2 control units, Net2 nano is designed to work seamlessly in the event of communications failure. It will continue to permit or deny access to users as appropriate. Once communications are re-established the activity is reported back to the PC.

Other hardware features:

- Volt free control relay
- Input for PSU fail
- Input for tamper
- Integrated lock diodes



with Plastic cabinet 654-772-EX