

Connecting Aritech ATS 1192 proximity reader to Net2


Overview



The reader tested has a 48 bit Wiegand output, and this appears to be fixed, rather than token dependent.

Therefore, a custom Wiegand rule will need to be created within the Net2 software.

Cable Pinout	ACU terminal
Red	+12V
Brown	Red LED
-	Amber LED
Yellow	Green LED
Green	Wiegand D0
White	Wiegand D1
-	NOT USED
Black	0V



Ensure any unused wires are safely terminated.


To configure the LED setting, open the Net2 server configuration utility and on the 'General' tab, check the 'Display reader LED's in OEM style' box.

If the option is not available, please contact Technical support for further advice.


 ☎ +44 (0)1273 811011
 ✉ support@paxton.co.uk
 📞 paxton.support



 ☎ +49 (0) 251 2080 6900
 ✉ support@paxton-gmbh.de
 📞 paxton.gmbh.support



 ☎ +33 (0)157 329356
 ✉ support@paxtonaccess.fr
 📞 paxton.support



 ☎ +32 (0)78485147
 ✉ support@paxton-benelux.com
 📞 paxton.benelux.support



 ☎ +31 (0)76 3333 999
 ✉ support@paxton-benelux.com
 📞 paxton.benelux.support


 ☎ +27 (0)21 4276691
 ✉ support@paxtonaccess.co.za
 📞 paxton.support


 ☎ +1(800) 672-7298
 ✉ supportUS@paxton-access.com
 📞 usapaxton.support


 ☎ +11 5715088198
 ✉ soporte@paxton-access.com
 📞 paxton.soporte


 ☎ +1 (864) 751-3501
 ✉ soporte@paxton-access.com
 📞 paxton.soporte


 ☎ 8000 3570 3783
 ✉ support@paxtonaccess.ae
 📞 paxton.support


 ☎ +44 (0)1273 811011
 ✉ support@paxton.co.uk
 📞 paxton.support