

# Connecting a Impro MDR HRW900-5-0-GB to Net2

## Overview


The reader was tested using Net2 6.01.83.19 software, configured to wiegand output to 26 bits. The reader operating mode used was 'Token only' using Mifare classic 1K card format.

When a token is presented to the reader the orange LED flashes, upon access granted and access denied. The reader beeps to acknowledge that a token has been presented.

The readers emits a solid orange LED when not is use.



Cable Pinout	ACU terminal
-	+12V
-	Red LED
-	Amber LED
-	Green LED
White	Wiegand D0
Green	Wiegand D1
-	NOT USED
Black	0V



Ensure any unused wires are safely terminated.



+44 (0)1273 811011  
support@paxton.co.uk  
paxton.support



+49 (0) 251 2080 6900  
support@paxton-gmbh.de  
paxton.gmbh.support



+33 (0)157 329356  
support@paxtonaccess.fr  
paxton.support



+32 (0)78485147  
support@paxton-benelux.com  
paxton.benelux.support



+31 (0)76 3333 999  
support@paxton-benelux.com  
paxton.benelux.support



+27 (0)21 4276691  
support@paxtonaccess.co.za  
paxton.support



+1(800) 672-7298  
supportUS@paxton-access.com  
usapaxton.support



+11 5715088198  
soporte@paxton-access.com  
paxton.soporte



+1 (864) 751-3501  
soporte@paxton-access.com  
paxton.soporte



8000 3570 3783  
support@paxtonaccess.ae  
paxton.support



+44 (0)1273 811011  
support@paxton.co.uk  
paxton.support