


HID ICLASS R30

Overview


The reader was tested on a Net2 Plus control unit with Net2 v6.05.9717.4442 using Mifare Classic.

To set up configure the reader in Door Reader settings using the following settings. Set the Reader Type as Weigand Reader, Token Data format as Weigand 26 bit and Token Type as Token Only.

Upon a valid token being presented the reader beeps.



Cable Pinout	ACU terminal
Red	+12V
-	Red LED
-	Amber LED
-	Green LED
Green	Wiegand D0
White	Wiegand D1
-	NOT USED
Black	0V




Ensure any unused wires are safely terminated.


For further information please visit the manufacturers website: <https://www.hidglobal.com/>


 +44 (0)1273 811011
 support@paxton.co.uk
 paxton.support


 +49 (0) 251 2080 6900
 support@paxton-gmbh.de
 paxton.gmbh.support


 +33 (0)157 329356
 support@paxtonaccess.fr
 paxton.support

 +32 (0)78485147
 support@paxton-benelux.com
 paxton.benelux.support

 +31 (0)76 3333 999
 support@paxton-benelux.com
 paxton.benelux.support

 +27 (0)21 4276691
 support@paxtonaccess.co.za
 paxton.support

 +1(800) 672-7298
 supportUS@paxton-access.com
 usapaxton.support

 +11 5715088198
 soporte@paxton-access.com
 paxton.soporte

 +1 (864) 751-3501
 soporte@paxton-access.com
 paxton.soporte

 8000 3570 3783
 support@paxtonaccess.ae
 paxton.support

 +44 (0)1273 811011
 support@paxton.co.uk
 paxton.support